

MODEL: 50005AWD

## ASSEMBLY INSTRUCTIONS


READ AND SAVE THESE INSTRUCTIONS

### UNPACK THE FOUNTAIN


YOU SHOULD HAVE RECEIVED THE FOLLOWING PARTS:  
FOUNTAIN BODY, LID, PUMP WITH LIGHT, EXTRA HALOGEN  
BULB, TRANSFORMER, (2) CORD COVERS, CHANNEL, (2)  
PLASTIC ANCHORS AND (2) WOOD SCREWS.

### FOUNTAIN ASSEMBLY

1. FEED PUMP POWER CORD THROUGH HOLE IN  
RESERVOIR TOWARDS BACK OF FOUNTAIN BODY.




FRONT VIEW




BACK VIEW

2. ATTACH PUMP TO RUBBER HOSE AND PLACE  
THE PUMP FLAT IN RESERVOIR.



3. SLIDE BULB INTO BULB CLIP ON BOTTOM  
OF LID, THEN PLACE LID INTO RESERVOIR TO  
COVER THE RESERVOIR.




4. LOCATE DESIRED POSITION ON WALL.

MODEL: 50005AWD  
**ASSEMBLY INSTRUCTIONS**  
 READ AND SAVE THESE INSTRUCTIONS

**FOUNTAIN ASSEMBLY**

**5. INSTALL WALL ANCHORS IN WALL AND HANG FOUNTAIN SECURELY ON BRACKETS. (HARDWARE NOT INCLUDED. CONTACT YOUR LOCAL HARDWARE PROFESSIONAL TO CHOOSE AN ATTACHMENT MECHANISM APPROPRIATE FOR YOUR WALL)**




**BACK VIEW**

**6. TO INSTALL CORD COVER, MOUNT CHANNEL ON THE WALL WITH WOOD SCREWS AND ANCHORS. PLACE CORD INSIDE CHANNEL AND PRESS CORD COVER SECURELY ONTO CHANNEL.**




**CORD COVER**



**CORD COVER**

AVAILABLE PARTS ARE:  
 50001TRANS (TRANSFORMER)  
 50001PMP (PUMP)

**7. JOIN THE CONNECTORS TOGETHER.**



**8. FILL RESERVOIR WITH 0.4 GALLONS OF WATER TO COMPLETELY SUBMERSE THE PUMP. NOTE: DISTILLED WATER IS RECOMMENDED TO REDUCE MINERAL DEPOSITS AND BACTERIA BUILD-UP.**

**9. PLUG TRANSFORMER INTO SOCKET AND TURN ON AT SWITCH, YOUR NEW FOUNTAIN IS READY FOR USE.**

**TROUBLE SHOOTING:**

1. IF YOUR FOUNTAIN DOES NOT WORK, CHECK PLUG AT THE SOCKET. MAKE SURE THE PLUG IS FULLY AND PROPERLY INSERTED INTO THE WALL OUTLET.
2. NEXT CHECK TO MAKE SURE THE OUTLET IS POWERED.
3. IF THE FOUNTAIN STILL DOES NOT WORK, PLEASE CONTACT YOUR DISTRIBUTOR OR PLACE OF PURCHASE.

**SPLASHING DISCLAIMER:**

SPLASHING MAY OCCUR WHEN FOUNTAIN IS INITIALLY TURNED ON. PROTECT SURROUNDING SURFACES AS NEEDED.

**IMPORTANT PUMP INFORMATION:**

PUMP MUST BE FULLY SUBMERSED IN WATER WHILE OPERATING.

**WATER:**

TO REDUCE MINERAL DEPOSITS AND BACTERIA BUILD UP THE USE OF DISTILLED WATER IS RECOMMENDED.

**IMPORTANT SAFETY INSTRUCTIONS:**

THIS FOUNTAIN IS RATED FOR INDOOR USE ONLY.

**WARNING:**

\* ONCE A WEEK INSPECT FOUNTAIN, FLOOR AND ADJACENT WALL FOR MOISTURE BUILD-UP AND CLEAN AS NECESSARY. THIS IS ESPECIALLY IMPORTANT FOR HUMID ENVIRONMENTS.

\*\* THIS UNIT MUST BE CONNECTED TO A SUPPLY CIRCUIT THAT IS PROTECTED BY A GROUND FAULT CIRCUIT INTERRUPTER (GFCI). THE GFCI SHOULD BE TESTED ON A ROUTINE BASIS. TO TEST THE GFCI, PUSH THE TEST BUTTON. THE GFCI SHOULD INTERRUPT POWER. PUSH THE RESET BUTTON. POWER SHOULD BE RESTORED. IF THE GFCI FAILS TO OPERATE IN THIS MANNER, THE GFCI IS DEFECTIVE.